

A) Unlock and activate the device



1. Unlock / Lock

Push the slider forward to „Ready“ in order to unlock the device.

Push the slider back to „lock“ in order to lock the mechanism.

2. Activate

Move your thumb under the protective hood and push down the trigger in order to release the spray.

Caution!

B) Important characteristics of the KKS Pistol Grip

1. Theft-/ Removal - Protection

This special feature attached to the slider may be connected to a spiral cord. It is a protection against removal of the spraying device from the hands or the holster of the user. Once the spraying can is inadvertently removed, the slider slips out and makes the device inoperative. When the can is retrieved, push the slider back in and the device is operational again.

2. Grip Shell

The pistol grip was specifically constructed to withstand increased strains and to offer absolute safety to the user even in dangerous situations. The shell fully encloses the upper third of the can and thus almost completely prevents the common soft spots (3.) from bursting.

